

## Which applications need Ultra?

The following is a general list of who does and doesn't need Ultra, keeping in mind that you can never go wrong with using a higher grade epoxy system than you need:

**Industrial and Commercial Maintenance Shops**, metal shops, large race shops, industrial machine shops need Ultra, precision machine shops with enclosed CNC machines can use the Ultra System or the [Armor II System](#), most wood shops can use the Armor II System.

**Floors With Extra Large Heavy Forklifts** or high forklift traffic need Ultra, floors with small forklifts, pallet jacks and low traffic can use the Armor II System.

**Animal Facilities** All types of animal facilities such as Dog Kennels, Animal Hospitals, Operating Rooms etc. This floor offers a pet friendly surface, an owner friendly surface as in easy to clean and maintain and is virtually an indestructible floor surface. This is the floor you want, that will last 20 or more years.

**Retail Floors** with very high foot traffic and or shopping cart traffic should use Ultra, floors with high rolling material cart traffic or heavy material cart traffic must use Ultra, low and or light rolling material cart traffic can use the Armor II system, high repetitive traffic whereas people, carts, dollies, forklifts, vehicles etc travel continuously over the same path must use Ultra since these types of floors are most susceptible to wear paths.

**High Volume Auto Service Centers** -use Ultra, low volume auto centers can use Armor II system, any floor with high/heavy steel wheel traffic must use Ultra, low/light or infrequent steel wheel traffic can use Armor II System.

**Commercial Kitchen Floors** should use Ultra, most aircraft hangars should use Ultra, hangars with light aircraft, helicopters and infrequent usage can use the Armor II System, laboratories with chemical exposure should use Ultra, laboratories with no chemical exposure can use the Armor II System.

**Commercial Parking Garages** should use Ultra, large personal garages/shops can use the Armor II System, most showrooms can use the Armor II System, large cafeterias should use the Ultra System, computer rooms and data center floors can use the Armor II System, high traffic restaurant floors should use the Ultra System. The above should give you a good idea of when to use which epoxy but if you're still not sure gives us a call to discuss your particular floor application.